

DVD CAM Software Support Center


Software Tutorials

Driver Operation Manual: To stop PC connection and disconnect Hitachi DVD Camera / Recorder


After transferring image files from Hitachi DVD Camera / Recorder, you may want to stop the PC connection removing Hitachi DVD Camera / Recorder from your PC. Follow the procedure as below. Incorrect procedure may cause your PC to freeze or crash.

For Windows 98 / 98SE / Me (Screen shot example: Windows 98)

1. Open "My Computer" or "Windows Explorer" and select the icon of the drive recognized as Hitachi DVD Camera / Recorder as below.



2. Select "Eject" from right mouse click menu as below. The disc in Hitachi DVD Camera / Recorder will be unlocked with snapping sound and you can now safely remove the camera from PC connection. (If you only want to change your disc, you can eject the disc to insert another and close the drive. Then the new disc will be recognized.)





For Windows XP/2000 (Screen shot example: Windows XP)

1. Click the green arrow icon  in the task bar (shown at your right below corner)



2. Select "Safely remove Hitachi DVD CAMERA USB Interface" to disconnect.



* When double-click the green arrow icon  in the task bar, the dialog box appears. To remove Hitachi DVD Camera / Recorder select "Stop" button.

