



DVD CAM Software Support Center

DVD-MovieAlbum Tutorials

How to Export a Still Picture from a Movie


1. Connect the DVD CAM with PC and start DVD-MovieAlbum.
2. Play a movie to find a scene you desire to export, and then pause to select a still picture.




3. Click the tab  in the top right of the window and click **File Export > Still Picture Export**.



4. In the **Still Picture Export** dialog box, adjust the selected still picture to be exported using the left and right arrow buttons ◀▶ .



5. Click the **Ref.** button to specify a location where the selected still picture is to be saved.



6. Click the **Start** button in the **Still Picture Export** window to save the still picture in the BMP file format.

